

This page lists the know errors on the gm5x5x5 PCBs.

## Prototype Run

### #1 MIDI IO pins

**Problem:** The MIDI IO pins of the midi sockets (Pin 4 + 5) are switched.

**Solution:** Either (1) sse the pin-headers if you use sockets that are not mounted on the pcb or (2) break the traces to pins 4 + 5 of the sockets and solder wires to them.

From:

<http://midibox.org/dokuwiki/> - **MIDIbox**

Permanent link:

[http://midibox.org/dokuwiki/doku.php?id=gm5x5x5\\_errata&rev=1227386187](http://midibox.org/dokuwiki/doku.php?id=gm5x5x5_errata&rev=1227386187)

Last update: **2008/11/22 20:36**

