

MB SEQ functions - quick reference

#	Function	Description / Options							
		Dedicated button functions (theese can vary depending on panel design and MBSEQ_HW.V4 file)							
1	Pattern 1,2,3,4	Select pattern/track group - G1, G2, G3, G4							
2	Track 1,2,3,4	Select track within track group - T1, T2, T3, T4 (16 tracks are available in total)							
3	Trigger layer A,B,C	Select trigger layer A or B or C. Holding C opens trigger layer selection menu and allows to select others <html>	Gate	Acc	Roll	Glide	Skip	R.G(random gate)	R.V(random value)
4	Parameter layer A,B,C	Select parameter layer A and B. C switches between C & D or if Pressed&Hold opens parameter layer selection menu and allows to select others <html>	Note	Vel	Length	Roll	</html> theese are default options, but CC, Pitch, Prob, Delay can be added via trigger selection menu (?)		No FX
5	Step View	View and select steps if more than 16 are used <html>	1..16	17..32	...etc				
4	a	b							

From:

<http://midibox.org/dokuwiki/> - **MIDibox**

Permanent link:

http://midibox.org/dokuwiki/doku.php?id=midibox_seq_quick_reference&rev=1273335382

Last update: **2010/05/08 16:16**

