

# AINSER64 Board parts list



[Official Ucapps Page](#)

## Parts List

 **Fix Me!** *Fill missings refs*

Description	Type	Quantity	Reichelt Ref	Mouser Ref	Digikey Ref
74HC595	IC	1	74HC 595	595-SN74HC595N	
MCP3208-CI/P	IC	1	MCP 3208-CI/P	579-MCP3208CIP	
CD 4051 BE	IC	8	MOS 4051	595-CD74HC4051M96	
10Ω	Resistor	1	1/4W 10	291-10-RC	
470Ω	Resistor	3	1/4W 470	291-470-RC	
100nF	Cap Ceram	3	Z5U-2,5 100n	80-C412C104K5R	
10µF	Cap Elec	1		667-EEA-GA1V100	
LED 3mm	Diode	3			
DIP16 Socket	Socket	10	GS 16	653-XR2A-1611-N	
DIL 2x5 Socket	Socket	10	PFL 10		
Jumper	Jumper	2	JUMPER2,54GL RT		

From:

<https://midibox.org/dokuwiki/> - **MIDIbox**

Permanent link:

[https://midibox.org/dokuwiki/doku.php?id=ainser64\\_board\\_parts\\_list&rev=1465348187](https://midibox.org/dokuwiki/doku.php?id=ainser64_board_parts_list&rev=1465348187)

Last update: **2016/06/08 01:09**

