Default Encoder Assignments

Each of the different engines have slightly different functions for the encoders but this should give you a list of the most common ones.

You can change them but this will give you a point of reference.

JD1

```
D0/D1 = LFO Rate
D2/D3 = Envelope Release
D4/D5 = LFO Depth
D6/D7 = Menu
```

JD2

```
D0/D1 = Oscillator Sustain
D2/D3 = Envelope Decay
D4/D5 = Oscillator Release
D6/D7 = Envelope Sustain
```

JD3

```
D0/D1 = Oscillator Attack
D2/D3 = Envelope Depth
D4/D5 = Oscillator Decay
D6/D7 = Envelope Attack
```

JD4

```
D0/D1 = ????
D2/D3 = Filter Cutoff
D4/D5 = Oscillator Delay
D6/D7 = Filter Resonance
```

college essay

From:
https://midibox.org/dokuwiki/ - **MIDIbox**

Permanent link:
https://midibox.org/dokuwiki/doku.php?id=default_encoder_assignments&rev=1310629885

Last update: **2011/07/14 07:51**