






C10
R39
R38
R37
R36
R2
R32
Q1
C8
C9
R23
J8
S2 S2 S1
OUT2
MAIN
LED11
R10
IN3
OUT IN
IO8



IC5
IC2
IC10
C5
LED4
OUT3
MAIN
LED11
R10
IN3
OUT IN
OUT3



GM5x5x5
build now. schem later.™
UL 94V-0
USB


GM5x5x5
build now. schem later.™
UL 94V-0
USB
S3 S2 S1 J8
jumper table
OUT2
IN2


GM5x5x5
build now, schem later
USB
IN1
OUT1
IN2
OUT2
IN3
OUT3
IN4
OUT4
IN5
OUT5
+5V
GND
YAGEO
WIMA
J2
USB POWER


YAGEO
WIMA
J4


GM5x5x5
build now, schem later™
UL 94V-0


YAGEO

From:
https://midibox.org/dokuwiki/ - **MIDIbox**

Permanent link:
https://midibox.org/dokuwiki/doku.php?id=gm5x5x5_noob_guide&rev=1235474696

Last update: **2009/02/24 11:24**