


MIDIBox AY 3 8912 - CS LED (wiring)

MIDIBox AY CS - Tone LEDs:



Tone LED Indication:

- Tone [A,B,C] On/Off
- Noise [A,B,C] ON/OFF


- Fx Option [A,B,C] ON/OFF

⋮

⋮


:

MIDIBox AY CS - Envelope LEDs:



Context:

- MIDIBox AY Envelope Control See ⇒ [midibox_ay_3_8912_envelope](#)



From:

<https://midibox.org/dokuwiki/> - **MIDIbox**

Permanent link:

https://midibox.org/dokuwiki/doku.php?id=midibox_ay_cs_led&rev=1269866585

Last update: **2010/03/29 12:43**

