


MB SEQ functions - quick reference

Detailed info for options and functions is available at http://www.ucapps.de/midibox_seq_manual_m.html

| # | Function | Description / Options | | | | | | | | | |
|---|-----------------------|--|--------|----------|---|-----------------------------|---------|------------------|-------------------|-------|---------|
| Dedicated button functions (these can vary depending on panel design and MBSEQ_HW.V4 file) | | | | | | | | | | | |
| 1 | Pattern 1,2,3,4 | Select pattern/track group - G1, G2, G3, G4 | | | | | | | | | |
| 2 | Track 1,2,3,4 | Select track within track group - T1, T2, T3, T4 (16 tracks are available in total) | | | | | | | | | |
| 3 | Trigger layer A,B,C | Select trigger layer A or B or C. Holding C opens trigger layer selection menu and allows to select others <html> | Gate | Acc | Roll | Glide | Skip | R.G(random gate) | R.V(random value) | No FX | </html> |
| 4 | Parameter layer A,B,C | Select parameter layer A and B. C switches between C & D or if <i>Pressed&Hold</i> opens parameter layer selection menu and allows to select others. Four parameter layers available by default, but CC, Pitch, Prob, Delay can be added via trigger selection menu (?)  | Note | Vel | Length | Roll | </html> | | | | |
| 5 | Step View | View and select steps if more than 16 are used <html> | 1..16 | 17..32 | ...etc</html> | | | | | | |
| 6 | Pattern | Select/load pattern/track group G1, G2, G3, G4 from SD memory location | | | | | | | | | |
| 7 | Song | Select song parameters <html> | Song # | Position | Action(Stop; x1..x16; Jump Pos; Jump Song; Mixer; Tempo; Mutes) | Select patterns G1,G2,G3,G4 | </html> | | | | |
| 4 | a | b | | | | | | | | | |

From:
<https://midibox.org/dokuwiki/> - **MIDIbox**

Permanent link:
https://midibox.org/dokuwiki/doku.php?id=midibox_seq_quick_reference&rev=1273336489

Last update: **2010/05/08 16:34**

