



THIS DOCUMENT IS CURRENTLY UNDER CONSTRUCTION



MSA (Mathmatical Sound Architecture)

MSA commands are stored in the 64-Byte input buffer and are executed in the order they are received.

MSA Controls

Pause

000: Pause 0 ms
001: Pause 100 ms
002: Pause 200 ms
003: Pause 700 ms

004: Pause 30 ms
005: Pause 60 ms
006: Pause 90 ms

016: Wait

Next Sound

007: Play next sound fast
008: Play next sound slow

014: Play next sound high
015: Play next sound low

====

From:
<https://midibox.org/dokuwiki/> - **MIDIbox**

Permanent link:
https://midibox.org/dokuwiki/doku.php?id=speakjet_control_overview&rev=1150034734

Last update: **2006/10/15 09:35**

