
Switch



Introduction

A switch is a small lever or button. It's an electrical device having two states, on (the closed state) or off (the open state). Ideally, a switch device has zero impedance when closed and infinite impedance when open. The switches on the back of printers and on expansion boards are called DIP switches. A switch that has just two positions is called a toggle switch.

From:
https://midibox.org/dokuwiki/ - **MIDIbox**

Permanent link:
https://midibox.org/dokuwiki/doku.php?id=switch&rev=1465305486

Last update: **2016/06/07 13:18**