


# AC Sensorizer v0.4





## Description

***AC Sensorizer sensorizes up to 8 sensors and interpolates its AIN-readings. The main target of this application are sensory devices delivering not exactly 0 - 5 V, like pressure-, distance-, resistor-based sensors or softPots.***



These two videos show the ACSensorizer 0.2 which is using an outdated HUI, but nevertheless the concept of the Sensorizer is demonstrated quite well:





The ACSensorizer has been developed by Audiocommander ( <http://www.audiocommander.de> )  
© 2007 Michael Markert

This software is released under a GNU License. You are not allowed to use this software or parts of it in closed-source projects! Please notice that due to the licenses for MBHP and MIOS you may only use the Hard- and Software for private purposes. Non-commercial use only!

Please contribute and name the author(s)!

## Features

- supports up to 8 sensors
- enable/disable single AINs
- **assignable CH and Controller-Number** or **Note\_On** generation (!)
- **harmonizer with 20 scales** (minor, major, blues, spanish...) ⇒ harmonizes generated or received (by MIDI!) note-signals
- **synchronizer**: master/slave mode (autodetect clock input switches to slave) and selectable BPM
- quantized events: 1/2/3/4/6/8/12/16/24/32/48, selectable per sensor
- **adjustable input range** by sense-min and sense-max (10bit values, ignore if not matched)
- **adjustable output range** with "scale from and scale to"
- sense-factor: used for signal interpolation... uses fast bitshifting or complex division depending on value
- AUTO-sense feature: **auto-calibration** of sensor, detect MIN/MAX and automatically adapts sense-factor!
- **invert** signal
- **pedal modes**:
  - filter ⇒ only forward if pedal down;
  - panic ⇒ send panic on release pedal;
  - combinations of all pedal mode options are possible
- **detect release**: send 0-value if signal drops below sense-min
- slowdown: slows down the signal and increases the gaps between generated values
- **bankstick** support: 1 connected bankstick provides 2 banks with 127 patches each (24LC256)
- midi configurable: full configuration possible with NRPN-messages
  - NRPN-MSB CC99 for sensorSelect / sysEx mode

- NRPN-LSB CC98 for controlType
- DataEntry MSB CC6 and LSB CC38 for controlValue
- **Mac OS X Onscreen Config Program** and MiniAudicle Setup Script examples included!
- LCD (2×16) with clearly structured menu for sensor-select, prg-select, sensor-config & -settings
- redesigned HUI Input to enable **better control with less hardware requirements**
- (optional) DOUT module supported (Sensors can be illuminated)
- ACSim Console Debugger: code integrated and ready to use configured for XCode
  - select “ACSim” as target and test the application via command-line
  - inspect variables with a (graphical) debugger (GDB support within XCode)
  - visit <http://www.midibox.org> → there's a tutorial how to use Code::Blocks

## Required hardware

### MBHP Modules:

- one MBHP\_CORE module
- one MBHP\_LCD module (2×16)
- one MBHP\_DIN module for
  - 4 Encoders (no push-button functionality needed!)
  - 1 PEDAL button
  - 1 PANIC button
  - 1 STORE and 1 WRITE button
  - 1 pedal-input (jack at the backside)
- one MBHP\_DOUT module for illuminated sensors (optional)

### Sensors:

- up to 8 sensors connected to unmuxed AIN (J5 of MBHP\_CORE).
- more informations on sensors can be found here: [sensors](#)



It is possible to use the sensorizer with only one Core Module. For these purposes a MAC OS X program is included to simulate encoders and buttons. You can easily test the application with one core module!

## Application Software

- [http://www.audiocommander.de/downloads/midibox/ACSensorizer\\_046.zip](http://www.audiocommander.de/downloads/midibox/ACSensorizer_046.zip), 324 kB, released on 2007-11-10
- still BETA, but quite stable
- Please report bugs or errors here: [ACSensorizer Forum Thread](#) – *audiocommander*

## Version History

- v0.1.0 2005-12: First testing versions, no code reused
- v0.1.1 2006-01: AIN-config, gate, expander, main functionalities
- v0.1.2 2006-01: Improved expander, inverter, smaller filesize
- v0.1.3 2006-04: Cleanup, code-splitting, rewrite (many fixes!)
- v0.1.4 2006-04: Improved inverter, expander, signal routing
- v0.1.5 2006-04: Added Bankstick Accessors (16byte / sensor)
- v0.1.6 2006-06: Rewrote Bankstick related functions, optimized vars
- v0.2.0 2006-07: Rewritten from scratch, optimized var-access & efficiency, added ENC and LCD menu (2×16/4×20 optimized) support (in main.c)
- v0.2.1 2006-08: Rewrote Bankstick Support (in main.c), 2×64 bytes per patch
- v0.2.2 2006-08: improved algorithms, added sensemode (efficient or exact), added pedalMode, releaseDetect config and PRG-CH, **initial release**
- v0.2.3 2006-09: minor bugfixing, removed MidiTrough and used MIOS\_Merger, two example miniAudicle/Chuck NRPN scripts are now included
- v0.2.4 2006-09: fixed severe bank select bug (B,D,F,H,J,L were not accessible)
- v0.3.0 2006-09: rewritten main class, better HUI concept, re-organized Encoder Input, autoload patch #0 (in case of reset), added pedal to start/stop AutoSense Mode, corrected sensor-level-view for sensors 4..8
- v0.3.1 2006-10: added Clock-Sync support / Continue-Hack for m4, added clock-forwarding, even if mios\_merger disabled
- v0.3.2 2006-11: fixed PRG-CH bug
- v0.4.0 2006-12: added harmonizer support, patches maintain full backward-compatibility to v0.2.1 versions
- v0.4.1 2006-12: added HUI Midi Remote Control (Simulate Encoder Movements)
- v0.4.2 2007-04: synchronizer support, unified ACMidiProtocol
- v0.4.3 2007-04: added bpm control (48..255 bpm), patches save harmonies & sync, fixed broken master/slave detection, CCs Sustain, Sustain & Soft Pedal (Damper) may also control the Pedal. Patch Names are now supported (7 chars max). Last active patch is stored in EEPROM and loaded on startup
- v0.4.4 2007-07: ENC\_Speed optimized for Voti.nl encoders, autosense bugfix, Documentation cleanup & updates, **release**
- v0.4.5 2007-08: sync start signal now recognized (SLAVE & MASTER), continue is sent each bar (MASTER), start on patch load (MASTER), harmonizer now working correctly with base notes, **release**
- v0.4.6 2007-11: fixed MST/SLV autodetection bug, now behaves correctly; PANIC also sends STOP in MASTER mode (LOAD sends START); Global Channel now defaults to CH16, messages are sent/received on all channels except for PRG\_CH (Global CH only) **release**
- v0.4.7 2007-11: Added DOUT support for external Sensors with LEDs; now recognizes QUANTIZE\_SET as well (ACMidiProtocol), fixed QUANTIZE\_BPM bug
- v0.5.0 2009: currently in work, future release will contain source compatibility maintenance for new toolchain, mac os x remote control & patch viewer... stay tuned!

## Compiling Notes

The application can be recompiled with a variety of strictly separated #define- options. For example setting SENSORIZER\_INTERFACE\_HUI to 0 compiles the application without hardware input controls and therefore reduces the file- and application space. Compiling without HUI, BANKSTICK, NRPN-Config and LCD generates code with approx. 3 or 4 pages; compiling with all options will result in an application file of 19 pages.

# HUI-Controllable Parameters

The Sensorizer provides:

- one 2x16 LCD
- four Encoders
- four Buttons



| Front Side |               |   |
|------------|---------------|---|
| Top        | Left Encoder  | current sensor selector (1..8)                    |
|            | Right Encoder | Menu Selection Wheel                              |
| Bottom     | White Button  | PANIC   |
|            | Green Button  | LOAD PATCH  |
|            | Red Button    | STORE PATCH                                       |
|            | Left Encoder  | Value setter for selected menu item / parameter 1 |
|            | Right Encoder | Value setter for selected menu item / parameter 2 |
|            | Black Button  | PEDAL (2nd pedal connector at the rear)           |




| Back Side     |                             |                      |                                |
|---------------|-----------------------------|----------------------|--------------------------------|
| Left          | 8 6-pin Mini-DIN connectors | For up to 8 Sensors  | Connector Type can be changed! |
| Middle        | 5-pin DIN connectors        | Midi-In and Midi-Out |                                |
| Middle Center | 6.5mm Jack                  | External Foot-Pedal  | A pedal is highly recommended! |
| Right Top     | Switch                      | ON/OFF Switch        |                                |
| Right Bottom  | DC Connector                | +9V DC Power Supply  | Connector Type can be changed! |


## Manual: Interface

The Interface is clearly structured; the encoders control the values on the screen next to them. A

minimum set of additional buttons allow loading and saving of patches, sending PANIC! and an alternative pedal knob (it is recommended to add a second pedal on the backside. MIDI pedals (like Sustainuto or Pedal are of course also supported).



## Manual: LCD-Menu



The following picture contains an overview of the onscreen LCD-menu structure. Click to view larger version:

The screenshot displays a MIDI configuration interface with the following parameters and values:

- Select:** [1]\_xxx<BANKPRG> IP!\_xxx< 0 | 0 > [1]\_xxx<BANKPRG> IP!\_xxx< 0 | 0 >
- Patch Name:** [1]\_xxx<\_PATCH > IP!\_xxx<Default> [1]\_xxx<\_PATCH > \_xxx<MyPr#0>
- Enable Sensors Debug Value:** [2]\_xxx<ENHANCED> \_xxx<OFF | 0 >
- CH / CC or NOTE\_ON:** [1]\_xxx<CH |CC > \_xxx< 1 |NTE > [1]\_xxx<CH |CC > \_xxx< 1 | 21 >
- Quantize Length BPM:** [1]\_xxx<0 |BPM > \_xxx< 16, |100 >
- Base Note Scale:** [1]\_xxx<BASISCL> \_xxx<C# |NRJ > [1]\_xxx<BASISCL> \_xxx<A# |nLb >
- Pedal Modes Release Detect:** [1]\_xxx<PEDIRLD> \_xxx<0x0 |NO > [1]\_xxx<PEDIRLD> \_xxx<0x2 |NO > [1]\_xxx<PEDIRLD> P!\_xxx<0x4 |NO > [1]\_xxx<PEDIRLD> P!\_xxx<0x6 |NO >
- Invert AutoSense:** [1]\_xxx<INVI/AUT> \_xxx<NO |OFF > [1]\_xxx<INVI/AUT> \_xxx<YES |OFF >
- AutoSense Minimum Value:** [1]\_xxx<INVI/AUT> \_xxx<NO |MIN > AUTO-SENSING PRESS PEDAL... AUTO-SENSING Mini: 22 Max:228
- AutoSense Maximum Value:** [1]\_xxx<INVI/AUT> \_xxx<NO |MAX > AUTO-SENSING PRESS PEDAL... AUTO-SENSING Mini: 22 Max:228
- Min/Max Sense Value:** [1]\_xxx<MIN/MAX > \_xxx< 2 |228 >
- Factor Slowdown:** [1]\_xxx<F |SLW > \_xxx< 4 | 8 >
- Scale From/To:** [1]\_xxx<FRH/TO > \_xxx< 0 |127 >
- Loading/Writing Patches:** Loading #C: 11 Patch: Default Writing #C: 11 Patch: Default

# MIDI Implementation Charts

See below which MIDI messages are recognized and sent by ACSensorizer:

| Message Type       | Received | Sent | Notes                |
|--------------------|----------|------|----------------------|
| NOTE ON            |          | X X  | Harmonized           |
| NOTE OFF           | X        | X    | Harmonized           |
| POLY AFTERTOUCH    |          | - -  |                      |
| CC                 |          | X X  | See CC Message Table |
| PROGRAM CHANGE     |          | G G  | Global Channel only  |
| CHANNEL AFTERTOUCH |          | - -  |                      |
| PITCH WHEEL        |          | - -  |                      |

Table A: MIDI Messages Implementation Chart

| CC    | Name                   | Received         | Sent | Notes                    |
|-------|------------------------|------------------|------|--------------------------|
| 0-127 |                        | <i>see below</i> | x    |                          |
| 0     | Bank Select            | G                | G    | Global Channel only!     |
| 6     | Data MSB               | x                | x    | See NRPN Table D         |
| 38    | Data LSB               | x                | x    | See NRPN Table D         |
| 64    | Pedal                  | x                | x    | Pedal                    |
| 66    | Sostenuto              | x                | x    | Pedal                    |
| 67    | SoftPedal              | x                | x    | Pedal                    |
| 80    | Harmony Base           | x                | x    | Harmony (ACMidiProtocol) |
| 81    | Harmony Scale          | x                | x    | 0..20                    |
| 82    | Harmony Base Listen    | x                | x    | <> 63                    |
| 83    | Harmony Scale Previous | x                | x    | > 63                     |
| 84    | Harmony Scale Next     | x                | x    | > 63                     |
| 85    | Harmony Random         | x                | x    | > 63                     |
| 87    | Quantize BPM           | x                | x    | BPM = [0..127] + 60      |
| 98    | NRPN LSB               | x                | x    | See NRPN Table C         |
| 99    | NRPN MSB               | x                | x    | See NRPN Table C         |

Table B: Controller Change Implementation Chart

- x** YES
- NO
- G** Global Channel only

The channel numbers that are counted from 1 to 16 appear as 0 to 15 in code!

For more information on [ACMidiProtocol](#) supporting interchangeable notifications on BPM, Harmony and Scale changes, see [ACMidiProtocol.h!](#)

### NRPN Controls

All Sensorizer parameters can be controlled and set by sending NRPN messages by MIDI:

1. Send NRPN MSB (Controller# 99) to select control type
2. Send NRPN LSB (Controller# 98) to set the control parameter
3. Send NRPN Data MSB (Controller# 6) and NRPN Data LSB (Controller# 38) to set the parameter value

| NRPN MSB   |            |               |                     |
|------------|------------|---------------|---------------------|
| CC         | Value      | Control Type  | Note                |
| CC99, 0x63 | 0x00..0x07 | Sensor 0..7   | LBS 98, See Table B |
| CC99, 0x63 | 0x60       | Sensor Wheel  | LSB 98, 0..8        |
| CC99, 0x63 | 0x61       | Menu Wheel    | LSB 98, 0..10       |
| CC99, 0x63 | 0x62       | Param Wheel A | LSB 98, 0..127      |
| CC99, 0x63 | 0x63       | Param Wheel B | LSB 98, 0..127      |

Table C: Control Types

| NRPN LSB   |       |                   | DATA ENTRY MSB/LSB    |         |   |
|------------|-------|-------------------|-----------------------|---------|---|
| CC         | Value | Control Parameter | CC                    | Value   | Description                             |
| CC98, 0x62 | 0x00  | enabled           | CC38, 0x26            | 0/1     | ON/OFF                                  |
| CC98, 0x62 | 0x01  | pedalMode         | CC38, 0x26            | 0..7    | FILTER/HOLD/PANIC/KOMBI                 |
| CC98, 0x62 | 0x02  | autoSense         | CC38, 0x26            | 0..2    | AUTOSENSE_OFF/_MIN/_MAX                 |
| CC98, 0x62 | 0x03  | invert            | CC38, 0x26            | 0/1     | 0..127 or 127..0                        |
| CC98, 0x62 | 0x04  | releaseDetect     | CC38, 0x26            | 0/1     | send 0 on release                       |
| CC98, 0x62 | 0x10  | slowdown          | CC38, 0x26            | 0..127  | drop AIN notifications                  |
| CC98, 0x62 | 0x11  | sense_min         | CC38, 0x26 & CC6, 0x6 | 0..1023 | drop below and set sense minimum        |
| CC98, 0x62 | 0x12  | sense_max         | CC38, 0x26 & CC6, 0x6 | 0..1023 | drop above and set sense maximum        |
| CC98, 0x62 | 0x13  | sense_factor      | CC38, 0x26            | 0..64   | $f=(\text{range}/127)$                  |
| CC98, 0x62 | 0x21  | scale_from        | CC38, 0x26            | 0..127  | restrict and rescale output             |
| CC98, 0x62 | 0x22  | scale_to          | CC38, 0x26            | 0..127  | restrict and rescale output             |
| CC98, 0x62 | 0x70  | CH                | CC38, 0x26            | 0..15   | MIDI Channel of sensor                  |
| CC98, 0x62 | 0x71  | CC                | CC38, 0x26            | 0..127  | MIDI Controller Change Number of sensor |

Table D: Control Parameters

**Examples:****Turning the Menu Wheel (virtually):**

1. Send NRPN MSB (Controller# 99) with value 0x61 to select control type
2. Send NRPN LSB (Controller# 98) with value 0 to 10 to set the control parameter
3. No NRPN Data MSB (Controller# 6) and NRPN Data LSB (Controller# 38) required

**Setting the CC to send for (already selected) sensor 1:**

1. Send NRPN MSB (Controller# 99) with value 0x00 to select the setting for sensor 1 (or 0x01 for sensor 2)
2. Send NRPN LSB (Controller# 98) with value 0x71 to set the control parameter "CC" for the selected sensor

- Send NRPN Data MSB (Controller# 6) with a value from 0 to 127 to set the CC Number. NRPN Data LSB (Controller# 38) is not required (only for values greater than 127)

## BANKSTICK Patch Description

ACSensorizer supports writing and reading to 24LC256-type banksticks.

Each patch consists of 2 pages à 64 bytes ⇒ 128 bytes

2 banks with 128 patches each are available per 1 connected bankstick (24LC256)

Choose the appropriate bank by sending a Coarse-Adjust Bankselect (CC#0).

In HUI-Mode, switching a bank on the device also sends the current Bank/PRG.

Memory-map of one patch:

| Data            | Size in Bytes = Sum | Page     | Address   |
|-----------------|---------------------|----------|-----------|
| Version         | 1 = 1               | 1 @ 0x00 | 0 @ 0x00  |
| PatchName       | 8 = 9               | 1        | 1 @ 0x01  |
| <reserved>      | 7 = 16              | 1        | 10 @ 0x0A |
| BPM             | 1 = 17              | 1        | 16 @ 0x10 |
| <reserved>      | 5 = 22              | 1        | 17 @ 0x11 |
| harmony_base    | 1 = 23              | 1        | 22 @ 0x16 |
| harmony_scale   | 1 = 24              | 1        | 23 @ 0x17 |
| sensor[8]       | 8 = 32              | 1        | 24 @ 0x18 |
| CH[8]           | 8 = 40              | 1        | 32 @ 0x20 |
| CC[8]           | 8 = 48              | 1        | 40 @ 0x28 |
| sync_1[8]       | 8 = 56              | 1        | 48 @ 0x30 |
| <reserved>      | 8 = 64              | 1        | 56 @ 0x38 |
| slowdown[8]     | 8 = 8               | 2 @ 0x40 | 0 @ 0x00  |
| sense_factor[8] | 8 = 16              | 2        | 8         |
| sens_min[8].MSB | 8 = 24              | 2        | 16 @ 0x10 |
| sens_min[8].LSB | 8 = 32              | 2        | 24        |
| sens_max[8].MSB | 8 = 40              | 2        | 32 @ 0x20 |
| sens_max[8].LSB | 8 = 48              | 2        | 40        |
| scale_from[8]   | 8 = 56              | 2        | 48 @ 0x30 |
| scale_to[8]     | 8 = 64              | 2        | 56        |

Table E: Bankstick Patch Content

Patch addresses are: (patch \* 0x80)

or PIC-optimized: (unsigned int)patch « 7

Example hex-output of patch#0 for Sensorizer > 0.4.0:

```

**MIOS_BANKSTICK_WritePage at 0x0
 0:    04 44 65 66 61 75 6c 74 00 ff 00 00 00 00 00 00 00 .Default.....
16:    78 00 00 00 00 00 00 00 14 81 81 81 81 00 00 00 00 x.....
32:    00 00 00 00 00 00 00 00 00 14 15 16 17 18 19 1a 1b .....
48:    08 08 08 08 08 08 08 08 00 00 00 00 00 00 00 00 00 .....
**MIOS_BANKSTICK_WritePage at 0x40
 0:    02 02 02 02 02 02 02 02 04 04 04 04 04 04 04 04 .....
16:    00 00 00 00 00 00 00 00 40 40 40 40 40 40 40 40 .....@@@@@@@
32:    03 03 03 03 03 03 03 03 70 70 70 70 70 70 70 70 .....pppppppp
48:    00 00 00 00 00 00 00 00 7f 7f 7f 7f 7f 7f 7f 7f .....

```

A reference to the last active patch (bank/prg) is stored in EEPROM to enable reloading on next startup. each time a patch is successfully loaded or stored the reference is automatically saved.

The available EEPROM address range is from 0xF00000 to 0xF000FF (256 bytes):

| EEPROM Address | Data       | Size (bytes) |
|----------------|------------|--------------|
| 0x00 - 0x01    | last bank  | 1 byte       |
| 0x01 - 0x02    | last patch | 1 byte       |
| 0x02 - 0xFF    | <reserved> | 254 bytes    |

Table F: EEPROM Content

# Step-By-Step Building Instructions

## 1. MBHP Core

Follow the instructions at [http://www.ucapps.de/mbhp\\_core.html](http://www.ucapps.de/mbhp_core.html). Don't forget to add MIDI-Cables and a 9V/800mA Power Supply!

## 2. MBHP LCD

Follow the instructions for a 2x16 LCD at [http://www.ucapps.de/mbhp\\_lcd.html](http://www.ucapps.de/mbhp_lcd.html)

## 3. MBHP DIN

Follow the instructions at [http://www.ucapps.de/mbhp\\_din.html](http://www.ucapps.de/mbhp_din.html)

## 4. MBHP DOUT

(optional) If you have lights on your Sensors, you can add a DOUT module:

[http://www.ucapps.de/mbhp\\_dout.html](http://www.ucapps.de/mbhp_dout.html)


### 5. MBHP Bankstick

Follow the instructions at [http://www.ucapps.de/mbhp\\_bankstick.html](http://www.ucapps.de/mbhp_bankstick.html). I'm using the Bankstick PCB supporting up to 8 Banksticks; maybe one Bankstick is sufficient for you (1 BS provides two banks with 127 patches each = 256 patches per Bankstick).



### 6. AIN "Breakout Board"

I use to solder extra 3-pin connectors on a separate PCB. These pins allow quick grounding with a jumper or to switch the sensors easily to check for hardware errors. And it's a lot smarter to assemble the case without having to desolder all connections ;)



### 7. AIN Cables

I'm using 6-pin Mini-DIN connectors. In theory, a three-pin connection would be sufficient, but with a 6-pin cable, I can use 2 pins for an external voltage supply or additional DIN/DOUT lines.




### 8. Encoders and Buttons



### 9. DIN Connections

Connect the Encoders and Buttons as shown on the following table. The DIN module has to be connected to J9 of core module (see [din\\_module](#) for connection diagram with SmashTV Core modules).

The following image is the upper view of a DIN-Board from Smash TV, [check this PDF if you are using the "standard" design from ucapps](#) (just note the name of the pins - D0,D1, D2, etc...):



### 10. DOUT Connection

(optional) Connect the Dout Pin #1 to a LED that sits in Sensor #1 (#2 to #2, #3 to #3 and so on...).

### 11. Upload MIOS

I'm running it with MIOS8 (PIC) 1.9e, but it should work with any newer 8-bit version. An update to the new app-structure is planned. See [Downloads...](#) and [MIOS8 Upload for Newbies](#)

### 12. Upload ACSensorizer

Upload "ACSensorizer.hex" /-OR-/ "ACSensorizer.syx" (depending on the method you are using... => see "Uploading an Application" at [MIOS8 Upload for Newbies](#))

### 13. Sensor Calibration

- Connect your sensors
- Disable all sensors but the first one (Menu: ENA => OFF)

- “from” should be “0” and “to” should be “127”
- Try Autocalibration first:
  - Menu: AUT → MIN ⇒ Trigger the minimum value of the sensor, then press the pedal. Release the pedal once you have the right minimum value.
  - Menu: AUT → MAX ⇒ Trigger the maximum value of the sensor, then press the pedal. Release the pedal once you have the right maximum value.
  - Menu: AUT → OFF
- Repeat these steps for the remaining sensors.
- If the automatic calculations aren't satisfying, which may be the case if you're using sensors with a “jumpy” behavior like IR Distance sensors, you can set the sensing MIN/MAX values by hand. Do not mix up with the Scale from/to values these are just to interpolate the final signal:
  - Measure the electrical min/max values or take them from the datasheet ( *Example: 0.2V min to 2.5V max* )
  - Calculate the 10bit minimum (Factor  $1024 / 5V = 204.8$ ) :  $0.2Vmin * 204.8 = 40.96 \Rightarrow$  as 8bit number:  $40.96 / 4 = 10.24 \Rightarrow$  Enter 15 as MIN. Note that the value is just shown as 8bit value, internally it's a 10bit value. That's why you need 4 Encoder detents to go from 128 to 129...
  - Calculate the 10bit maximum (Factor 204.8) :  $2.5Vmax * 204.8 = 512 \Rightarrow$  as 8bit number:  $512 / 4 = 128 \Rightarrow$  Enter 128 as MAX
  - Now set the sense-factor, Menu: F. The sensorized value gets divided by this factor to get the 7bit value. Normally this would be 8 ( $1024 / 127 = 8$ )  $\Rightarrow$  in our example:  $512 max (10bit) / 127 = 4 \Rightarrow$  Enter 4 as F
  - Proceed with the remaining sensors and Save your patch.

## Done!

This site is about to change while the Sensorizer is being developed further!

have fun! – audiocommander

From:

<https://midibox.org/dokuwiki/> - **MIDIbox**

Permanent link:

[https://midibox.org/dokuwiki/doku.php?id=acsensorizer\\_04&rev=1241303484](https://midibox.org/dokuwiki/doku.php?id=acsensorizer_04&rev=1241303484)

Last update: **2009/05/02 22:31**

